







微創 POS-335 一體成型POS主機 Touch Driver安裝教學

◎ POS335 開機無法觸控螢幕(TOUCH)，滑鼠可正常操作。請依以下步驟重新安裝 Touch Driver:

一、請於光碟片找到安裝檔或至微創官網「檔案下載→驅動程式」下載” [POS-335 \(Touch Driver\)](#)” 執行。



二、執行安裝檔案至結束(1~10)。Touch 功能即可正常使用。

<p>1</p>  <p>使用者帳戶控制 此檔案來自不受信任的位置。 是否確定要執行此檔案? 程式名稱: TouchUtility Setup-FH_v3.3.2.10_WHQL20121212.exe 檔案來源: 網路磁碟機 顯示詳細資料(D) 是(Y) 否(N) 此檔案位於區域網路之外的位置。來自您無法識別之位置的檔案可能會危害您的電腦。請僅執行來自您信任位置的檔案。 變更這些通知顯示的時機</p>	<p>2</p>  <p>TouchUtility Setup Welcome Welcome to the installer for TouchUtility 3.3.2.10- FH_WHQL It is strongly recommended that you exit all Windows programs before continuing with this installation. If you have any other programs running, please click Cancel, close the programs, and run this setup again. Otherwise, click Next to continue. < Back Next > Cancel</p>
<p>3</p>  <p>TouchUtility Setup License Agreement Please read the following license agreement carefully. License For Customer Use of TouchUtility Software IMPORTANT NOTICE - READ CAREFULLY: This License Agreement for use of TouchUtility Software ("LICENSE") is a legal agreement between you ("CUSTOMER") and TouchUtility Inc. ("TouchUtility") which governs use of the software contained on this media. This includes all software and documentation contained herein ("SOFTWARE"). By downloading, installing, copying, or otherwise using the SOFTWARE, you agree to be bound by the terms of this LICENSE. If you do not agree to the terms of this LICENSE, quit the install program now and do not install or use the SOFTWARE. RECITALS Use of TouchUtility's products requires three elements: the SOFTWARE, one or more pieces of TouchUtility hardware ("HARDWARE"), and a computer. The SOFTWARE is protected by <input checked="" type="radio"/> I agree to the terms of this license agreement <input type="radio"/> I do not agree to the terms of this license agreement < Back Next > Cancel</p>	<p>4</p>  <p>TouchUtility Setup Installation Folder Where would you like TouchUtility to be installed? The software will be installed in the folder listed below. To select a different location, either type in a new path, or click Change to browse for an existing folder. Install TouchUtility to: C:\Program Files\TouchUtility Change... Space required: 4.47 MB Space available on selected drive: 179.10 GB < Back Next > Cancel</p>
<p>5</p>  <p>TouchUtility Setup Shortcut Folder Where would you like the shortcuts to be installed? The shortcut icons will be created in the folder indicated below. If you don't want to use the default folder, you can either type a new name, or select an existing folder from the list. Shortcut Folder: TouchUtility <input type="radio"/> Install shortcuts for current user only <input checked="" type="radio"/> Make shortcuts available to all users < Back Next > Cancel</p>	<p>6</p>  <p>TouchUtility Setup Options Select the options you want and click Next to continue. Please select from the following options: <input checked="" type="checkbox"/> RS232 <input checked="" type="checkbox"/> USB Note: You may select as many options as you want. < Back Next > Cancel</p>

